

User Guide

Find My Device

Powerful Locator for Keys, Bags, and More



Works with

Apple Find My



Works with Android

Find Hub

The Tag is a universal item finder that works with the Apple Find My network or Find Hub network to help you locate your valuable items. During initial setup, you can select your preferred network. However, the finder cannot operate on both networks simultaneously. Once a network is selected, the other is automatically disabled. To switch networks, you must perform a factory reset on the finder.

Main Functions

Button instructions:

1. To turn on the device: Press the button briefly. A prompt tone will sound and the device will power on.
2. To check the status: Press the button briefly. A "beep" sound will indicate that the device is in working condition.
3. To turn off the device: Press and hold the button for more than 5 seconds. Three "beeps" will sound and the device will power off.

Apple Pairing the device:

1. Press and hold the device briefly to turn it on, and bring it close to your iPhone.
2. Open the "Find My" app on your iPhone.
3. Tap the "Items" tab, then tap the "+" sign and select "Add an Item".
4. When you see the name "Earth Tag", "Venus Tag", "Smart Finder Card" or "Other Name", tap to connect.
5. Name your device and select an emoji.
6. Tap "Agree" to confirm that the item will be associated with your Apple ID.
7. Tap "Done".

Enable Lost Mode:

1. Open the "Find" app, tap the item label, and then select your item.
2. In Lost Mode, tap Enable.
3. Read the guide, tap Continue and enter your phone number or email address for contact, then tap Next.
4. Confirm the custom lost message and tap Activate to complete the setup.

Remove the device:

1. Open the "Find" app, click on the item tag, and then select your item.
2. Click "Remove", and then click "Remove" again to complete the operation.
3. Press the button three times in quick succession, and then hold it down for the fourth time until you hear a long "beep~" sound.
4. At this point, the item has been restored to factory settings and can be paired with a new account.

Location and Notification

Open the "Find My" app, tap the item tag, and then select your item (the item has a location time display).

1. Locate the item when it is nearby

After selecting the item, tap "Play Sound", and the item will emit music, making it easy for you to locate it.

2. Find the item's location

After selecting the item, its location will be displayed on the map. To navigate to the item's location, tap "Navigate" to open Apple Maps.

3. Enable "Notify When Left Behind"

After selecting the item, turn on the "Notify When Left Behind" switch under "Notifications". When you leave the item and it is out of range of your device, you will receive a notification.

4. Enable "Notify When Found"

After selecting the item, turn on the "Notify When Found" switch under "Notifications". When your item is discovered by another device using the "Find My" app, you will receive a notification of its location.

Note: The "Notify When Found" switch can only be enabled when your item is out of your range.

Important Note:

When pairing devices using the "Find My" app, your phone will connect to Apple servers. The pairing may fail due to network issues. Here are some solutions:

1. Update your phone's network, such as switching between Wi-Fi and mobile data.
2. Reset the device: Press the button briefly three times in a row, and then press and hold it for the fourth time until you hear a long "beep" sound. Release the button to complete the reset.
3. Re-pair the device in the "Find My" app.

Steps for wireless connection of the anti-loss device.




1. Open the "Find" APP that comes with the system.



2. Select "Items" in the menu below.



3. Click the "+" and select "Add Other Items".



4. The product is turned on by pressing the button, and the APP is searching for items.



5. Search for items to be added. 6. Click the link and the prompt will name the item.



7. Name the "Find My" item. 8. Click "Continue" and it prompts to select emoticons.



9. Select the appropriate display symbol.



10. Click "Agree" to bind the item to your Apple account.



11. The prompt window for successfully binding an Apple account.



12. The interface for displaying the positions of items normally.

Google Editions

A.This manual is applicable to pairing, using and unbinding compatible tracking devices with designated Android phones through the Google "Find Hub" application. It aims to help users quickly master the device connection process and realize the management of functions such as positioning and sound of tracking devices.

B. Recommended Equipment and System Requirements To ensure the stable operation of the "Find Center" application and pairing function, it is recommended to use the following mobile phone models and their corresponding Android versions.

Non-recommended models may have function compatibility issues:

Recommended mobile phone models	Recommended mobile phone models
Google Pixel 8	Android 15
Samsung S23	Android 14
Google Pixel 7	Android 13
Google Pixel 6	Android 12
Google Pixel 5	Android 11
Samsung S20 and subsequent models	Android 12 or Android 13

C.Preparatory Conditions

a.Network environment configuration :


Due to the access restrictions of Google services, the mobile phone must be connected to a VPN network that can normally access Google services; otherwise, account login, app download and device pairing cannot be completed.

b.Google Account login:

1.Open the "Settings" app on your phone;

2.In the Settings page, click on the search bar at the bottom of the "account related ICONS" , according to the prompt to complete Google account login;

3. If not registered Google account, can the login page select "registration" option, complete account created as process fill in information.




D.Equipment Pairing Operation Steps

1.download and install the "find center" application to open a mobile phone "Google Play Store" .

2.Input "Google in the search bar, Find the Hub, Find the official application marked as "Google 's FindHub".

3.Click "Install". After the application is installed, click "Open" to start the application.




Activate the radio equipment guarantee for matching tracking devices and the distance between the mobile phone within 30 cm (the closer distance, the higher the matching success rate).


Complete automatic matching.

1."Start" find center, the phone automatically scan in a state of radio tracking devices near.

2.After scanning the device, a "pairing pop-up window" will automatically appear on the phone screen (the pop-up window shows the device name, such as "PearlsRadiant"). Click the "Connect" button in the pop-up window.



3. After jumping to the "Terms of Use" page, carefully read the "Search Center Acceptable Use Policy" (subject to laws and regulations, it is prohibited to track others without consent, otherwise legal responsibility may be borne). After confirming that there are no errors, click "Agree and Continue" to complete the matching.




E.Steps for Unbinding the Equipment

1:a. download and install the "find center" application to open a mobile phone "Google Play Store".


b.Input "Google in the search bar, Find the Hub" (Find),
Find the official application
(marked as "Google 's FindHub")

c.Click "Install" . After the
application is installed,
click "Open" to start the
application.



2.Remove devices in the device details page, click on the"removed from 'search center" (Remove the from the Find Hub) options; After the system confirms, the device will be removed from the "My Devices" list, and the unbinding is completed.matters need attention:

If the unbound equipment needs to be used again, the pairing process must be completed again in accordance with "IV. Equipment Pairing Operation Steps" of this manual.





BATTERY WARNING



Keep out of reach of children.
Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.



WARNING



Ingestion hazard:
This product contains a button cell or coin battery.
DEATH or serious injury can occur if ingested.
A swallowed button cell or coin battery can cause **INTERNAL CHEMICAL BURNS** in as little as **2 HOURS**.
KEEP new and used batteries **OUT OF REACH OF CHILDREN**.
SEEK IMMEDIATE MEDICAL ATTENTION if a battery is suspected to be swallowed or inserted inside any part of the body.